





















Ref. cislo	Obj. cislo	Popis
Spotrebne diely vhodné pre ESAB® (L-Tec®) PT 20 AM		
21150	HG 1562	 Elektroda
21330 21329 21328	HG 1590 HG 1568 HG 1567	 Tryska Ø 1,1 - .039 50 Amp..... Tryska Ø 1,3 - .051 70 Amp..... Tryska Ø 1,5 - .059 100 Amp.....
Spotrebne diely vhodné pre ESAB® (L-Tec®) PT 23 / PT 27		
33366	HG 1591	 Elektroda
33367	HG 1597	 Rozvadzac vzduchu.....
33368 33369 33418	HG 1592 HG 1593 HG 1594	 Tryska Ø 0,93 mm - .037 30 Amp..... Tryska Ø 1,16 mm - .046 50 Amp..... Tryska Ø 1,32 mm - .052 80 Amp.....
21616	HG 1598	 Ochranna krytka (PT 27).....
21420	HG 1599	 Distančne teliesko (2 hroty)
Spotrebne diely vhodné pre ESAB® (L-Tec®) PT-24®		
21539 21539	HG 1332 HG 1333 HG 1330	 Elektroda 15/100A..... Elektroda 15/100A, striebro HOLMA BLUE LINE O-kruzok.....
21852 21536 21692	HG 1339 HG 1340 HG 1341	 Rozvadzac vzduchu 15 Amp (2 dierky)..... Rozvadzac vzduchu 30 Amp (3 dierky)..... Rozvadzac vzduchu 50/100 Amp (4 dierky).....
21540 21541 21542 21543 21923	HG 1334 HG 1335 HG 1336 HG 1337 HG 1338	 Tryska 15A "A"..... Tryska 30A "B"..... Tryska 50A "C"..... Tryska 70A "D"..... Tryska 100A "E".....

Ref. cislo	Obj. cislo	Popis	
Spotrebne diely vhodne pre ESAB® (L-Tec®) PT 19XL			
34086XL	HG 1320	 Elektroda O2	
22028	HG 1322	 Zakladna na trysku 100-200A	
22029 22030 22031	HG 1323 HG 1324 HG 1325	   Tryska 100A Tryska 150A Tryska 200A	
21822	HG 1326	 Tryska 250A	
Spotrebne diely vhodne pre ESAB® (L-Tec®) PT-32			
0558001969	HG 1553	 Elektroda Nove!!	
0558002908	HG 1554	 Tryska 40 Amp.	
0558002618	HG 1555	 Tryska 50-70 Amp.	
0558002837	HG 1556	 Tryska 90 Amp.	